



# Electric Eraser (Battery Operated)

NO.:EE-0001





1. Transparent Cover



2. Big Comfortable Switch



# Electric Eraser







# Electric Eraser

accessories:  
Two plastic rubber jacket  
2.5mm rubber right  
5mm rubber right



plastic jacket



BATTERY  
DRIVER



BATTERY  
COVER

Keep Smiling is the art of living!

# Artist Fine Electric Eraser





# Electric Eraser

accessories:

- Two plastic rubber jacket
- 2.3mm rubber eight
- 4mm rubber eight



THICKNESS



BATTERY  
CRUSH




SMART  
COVER

Keep Smiling is the art of living!

# ADJUST ERASER REFILL



- 1** Remove adapter and eraser refill.



- 2** Adjust to 3MM (1/8")



- 3** Install adapter and eraser refill.







# Electric Eraser

accessories:

- Two plastic rubber jacket
- 2.3mm rubber sight
- 5mm rubber sight



THICKNESS



BATTERY  
GREEN



SMART  
COVER

Keep Smiling Is the art of living!

# **PURCHASE INCLUDES THE FOLLOWING:**



**ELECTRIC ERASER**



**8 SMALL REFILLS**



**TWO ADAPTERS**



**8 LARGE REFILLS**



# Electric Eraser

accessories:

- Two plastic rubber jacket
- 2.3mm rubber eight
- 5mm rubber eight



BATTERY DRIVEN



SMART COVER

Keep Smiling is the art of living!

## **2.3mm Eraser (plastic holder)**

Erase smaller areas



## **5mm Eraser (metal holder)**

Erase bigger areas

# OPERATION



- 1** **Remove Cover:** Push down to remove battery cover.



- 2** **Install Batteries:** Put in two 1.5V AAA batteries.



- 3** **Install Cover:** Align cover and snap closed.



- 4** **Retract Ring:** Push protection ring down to retract.



- 5** **Extend ring:** Grasp ring with finger tips, pull up to extend.



- 6** **Press Button:** Press and hold button to operate eraser.