







Specific For Fine Arts Design

Refill Eraser For Art/design (Highlight/pencil /crayon General)

Replacement Method Of Rubber Core Replace the refill as shown in the figure, press the cap, pull out the rubber refill that needs to be replaced from the pen tip, and then install a new refill from the pen tip









