



• Never clean the safety shield with
your hands.
• Do not touch the blade after
it has been retracted.
• Do not touch the blade after
it has been retracted for a long
period of time.
• Do not touch the blade after
it has been retracted for a long
period of time.

AllPro
3312

WARNING
Do not touch the blade after
it has been retracted for a long
period of time.





• Press down the safety shield firmly when cutting.
• Drücken Sie den Sicherheitschutz fest beim Schneiden.
• Appuyer fermement sur le barreau de protection pour couper.
• Al cortar presione firmemente el protector de seguridad.

KU-trio®
3912

WARNING
Read the instructions before using the trimmer.
Do not touch the blade when the trimmer is running.
Do not touch the blade when the trimmer is stopped.
Do not touch the blade when the trimmer is being moved.
Do not touch the blade when the trimmer is being cleaned.







500
51171

0.01

0.01

Model	13912
Cutting Length	335 mm
Cutting Height	2.0 mm
Blade Type	Knife
Clamping Type	press
Blade Guard	ABS shield
Knife Lock	V
Measuring Scale	mm/inch
Format Indication	A6-A4
Table Size (WxD)	305 x 380 mm
Dimensions (WxDxH)	335 x 430 x 380 mm
Weight	3.62 kg
Color	Blue

