















shake



release air



press



write

1. Shake well before use.
2. Press down the nib and hold for 3 or 4 seconds to release air.
3. Press the nib several times until the ink appears.
4. Try a line on the paper.
5. Start using best quality paint marker



M&G
เครื่องเขียน



M&G 晨光

油性
中字

油漆笔 P01

AOMY8501 PAINT MARKER
12支/盒

PAINT
油漆笔 P01

PAINT
油漆笔 P01



适用于油漆、塑料、金属、陶瓷、木头、玻璃、铝塑板等表面

PAINT

油漆笔
MARKER

P01





